
Charge Sensing

Simon Geyer – 02.04.2020


Problem: Measure QD at last electron/hole

- reducing number of electrons/holes reduces tunnel rate
- Is this the last hole or is the transport current just too small to measure?



Solution: Charge Sensing

- Measures change of charge
- sensitive to electrostatic changes (high dl_Sens/dV)
- different types:
 - Quantum point contact (QPC)
 - Single-electron transistor (SET)
 - Sensing QD



Charge Sensing with QPC

PHYSICAL REVIEW B 67, 161308(R) (2003)

Few-electron quantum dot circuit with integrated charge read out


```
J. M. Elzerman, R. Hanson, J. S. Greidanus, L. H. Willems van Beveren, S. De Franceschi, L. M. K. Vandersypen, S. Tarucha, S. Tarucha, And L. P. Kouwenhoven Department of NanoScience and ERATO Mesoscopic Correlation Project, Delft University of Technology, P.O. Box 5046, 2600 GA Delft, The Netherlands

2NTT Basic Research Laboratories, Atsugi-shi, Kanagawa 243-0129, Japan


3ERATO Mesoscopic Correlation Project, University of Tokyo, Bunkyo-ku, Tokyo 113-0033, Japan (Received 6 February 2003; published 30 April 2003)
```

Dutch

QPC



- 1D confinement -> quantized conduction (2e²/h)
- high dI/dV at steps




B. J. van Wees, Phys. Rev. Lett. 60, 848 (1988)


also Dutch

Device

 Double dot with 2 adjacent QPCs (now only used as single dot)



 Left QPC quantized conduction steps



DRAIN1

SOURCE2

QPC-L

QPC-R


SOURCE1

L P M P R


200 nm

a


- I_QPC increases linear, kink occurs when electron is loaded to QD
- For inset: subtract linear background
 - -> sudden jump in I_QPC when dot changes occupancy number
- Sensitivity ~0.1e



Comparing Transport/Charge Sensing



- Coulomb oscillations in transport coincide with dips in dI_QPC/dV_M
- QPC can measure charge state transistions in QD
- works even when barriers of the QD are very opaque (no transport current measureable)



Comparing Charge Sensing/Transport

DRAIN1

SOURCE2

QPC-L

QPC-R


I_QPC

SOURCE1

DRAIN2


200 nm

• In DQD:




Measure absolute Charge in QD

• Empty QD, then count



Only with Charge Sensing: Inter-dot transitions



Detecting single electrons

- So far: we measured averages of many transitions
- Now: measuring a single electron tunnelling event

Nature **423**, 422–425(2003)


Real-time detection of electron tunnelling in a quantum dot

Wei Lu*†, Zhongqing Ji*, Loren Pfeiffer‡, K. W. West‡ & A. J. Rimberg*§

Not Dutch

Charge Sensing with a SET

- basic idea similar to QPC: tune SET in high dI/dV regime
- here: more complex RF read-out at 1GHz
- Amplitude of reflected RF signal is sensitive to dR/dV of SET




R. J. Schoelkopf et al., Science 280 5367 (1998)

Testing SET Charge Sensing


- deplete QD
- modulate Q_SET with 100kHz signal
- $\Delta Q_SET \sim 0.1e$

• -> RF readout works



SET Charge Sensing with QD


- now with QD close to transition from N to N+1 electrons
- random telegraph noise (RTS) is induced by QD occupancy:
 - lower level: N electrons
 - upper level: N+1 electrons
- -> we can see single tunnelling events




Analysis of RTS

- NC = # transitions
- If QD level is aligned with reservoir -> high NC

 -> Coulomb oscillations are visible




Probing Charge Degeneracy Point



Total Tunnelling Rate

- Tunnel coupling $\Gamma = \Gamma_0 + \Gamma_1$
- Lorentzian power spectrum

$$S_{\nu} \propto \frac{1}{\Gamma^2 + (2\Pi_{\delta})^2}$$



Summary

- charge sensor reads charge transitions in adjacent QD
- sensitiv, fast, strong signal for low current
- QDs which are not connected to reservoirs can be measured
- a single electron tunnelling process can be resolved
 - -> towards single shot spin read out